

KPE-LE02 Digital Keypad for VFD-E Series

Instruction Sheet


- ◆ Please thoroughly read this instruction sheet before installation and putting it into use.
- ◆ The content of this instruction sheet and the driver file may be revised without prior notice. Please consult our distributors or download the most updated instruction version at <http://www.delta.com.tw/industrialautomation/>.

1 Description of the Digital Keypad



- A** Status Display
Displays the drive's actual status.
- E** LED Display
Indicates frequency, voltage, current, user defined units, etc.
- C** Potentiometer
Please set the right parameters for master Frequency setting.
- D** RUN Key
Please set the right parameters to start AC drive operation.
- G** STOP/RESET
Please set the right parameters to stop AC drive operation and to reset the drive after a fault occurred.
- H** ENTER
Used to enter/modify programming parameters

2 Dimensions in mm [inch]




3 Display Messages

Display Message	Descriptions
	Displays the AC drive Master Frequency.
	Displays the actual output frequency at terminals U/T1, V/T2, and W/T3.
	User defined unit (where U = F x Pr.00.05)
	Displays the output current at terminals U/T1, V/T2, and W/T3.
	Displays the AC motor drive forward run status.
	Displays the AC motor drive reverse run status.
	The counter value (C).
	Displays the selected parameter.
	Displays the actual stored value of the selected parameter.
	External Fault.
	Displays "End" for approximately 1 second if input has been accepted by pressing ENTER key. After a parameter value has been set, the new value is automatically stored in memory. To modify an entry, use the  and  keys.

Display Message	Descriptions
	Displays "Err", if the input is invalid.

4 How to Operate the Digital Keypad

Setting Mode



NOTE: In the selected mode, press **ENTER** to set the parameters.

Setting parameters



NOTE: In the parameter setting mode, you can press **ENTER** to the selected mode.


To change data



Setting direction (When operation source is digital keypad)




Setting PLC Mode




5 Installation

Method 1. Direct installation (unit: mm[inch])




Method 2. Mounting by the plate thickness (unit: mm[inch])

A. Thickness=1.2mm[0.05 inches]



B. Thickness=2.0mm[0.08 inches]



KPE-LE02 VFD-E 系列之數位操作器

說明書


- ◆ 請詳細閱讀下列說明後才使用本產品，以確保使用安全。
- ◆ 由於產品精益求精，當內容規格有所修正時，請洽詢代理商或至台達網站 (<http://www.delta.com.tw/industrialautomation/>) 下載最新版本。

1 鍵盤面板外觀



- A** 狀態顯示區
分別可顯示驅動器的運轉狀態運轉、停止、寸動、正轉、反轉等
- B** 主顯示區
可顯示頻率、電流、電壓、轉向、使用者定義單位、異常等
- C** 頻率設定旋鈕
可設定此旋鈕作為主頻率輸入
- D** 運轉鍵
可令驅動器執行運轉
- G** 停止/重置鍵
可令驅動器停止運轉及異常重置
- H** 參數資料設定鍵
用以讀取修改驅動器的各項參數設定

2 鍵盤面板鍵盤面板尺寸



3 功能顯示項目說明

顯示項目	說明
	顯示驅動器目前的設定頻率
	顯示驅動器實際輸出到馬達的頻率
	顯示用戶定義之物理量 (U = F x 00-05)
	顯示負載電流
	正轉命令
	反轉命令
	顯示計數值
	顯示參數項目
	顯示參數內容值
	外部異常顯示
	若由顯示區讀到 End 的訊息(如左圖所示)大約一秒鐘，表示資料已被接受並自動存入內部存貯器
	若設定的資料不被接受或數值超出時即會顯示